
ADJUSTING THE CUT PEEL OFFSET ON THE SUMIMARK IV 300DPI PRINTER

-On the Sumimark IV 300dpi printer press **PAUSE**

-Press **FEED** and **PAUSE** at the same time to bring up printer menu. It should say **PRINT MODE** on the front display if done correctly.

-Hold down the **FEED** button while pressing the **PAUSE** button to cycle menu forward or **CANCEL** to cycle back through the menu.

- Cycle to and stop on **Cut Peel Offset**

-Press **CANCEL** by itself once / **CUT PEEL OFFSET** on the display will flash

-Hold down the **FEED** button then press **PAUSE** to increase the value to **+012**. Pressing **CANCEL** will decrease the value. The setting should be between **+012** to **+014** only.

-Press **CANCEL** to lock in selection / **CUT PEEL OFFSET** will stop flashing

-Press **PAUSE** 2x which will take you back to the **READY** screen